

# A. B. DICK 360 T-51® STATIONARY T-HEAD

## Frequently Used Part Numbers

### Rollers

X07-51110	Form Roller, Soft
XSA-0702360TH	Metering Roller Assy., Hard (Roller, shaft, E-clip, collar, roll pin)
X07-0322NS	Pan Roller, Soft
XSA-070517	Upper Intermed. Assy., Soft (Roller, shaft, snap rings)
X07-51151	Lower Intermed. Roller, Soft
X07-0420	Oscillator Roller, Hard

### Miscellaneous

XSA-1126	Water Pan Assy. (w/ pan bolts)
X99-28	Water Pan Hose
XSA-9905	Water Bottle (w/cap)
X99-61	Wash Up Bottle
X88-51	Installation Manual


T-51® AND SWING-AWAY® ARE REGISTERED TRADEMARKS OF TOWNSEND INDUSTRIES.

### PRINTERS PARTS

800-543-1117 201-935-9595

fax 800-392-4072 201-935-5333

www.ppsnj.com



#### Adjustments

- Pan to Metering
- Form to Plate

#### Roller Description

P	=	Pan, Soft
M	=	Metering, Hard
UI	=	Upper Intermediate
LI	=	Lower Intermediate
O	=	Oscillator, Hard
F	=	Form, Soft