A. B. DICK 9800 T-51® STATIONARY T-HEAD

Frequently Used Part Numbers

Rollers

X07-51710 Form Roller, Soft

XSA-070298TH Metering Roller Assy., Hard

(Roller, shaft, collars, roll pin)

X07-0325NS Pan Roller, Soft

XSA-070521 Upper Intermed. Assy., Soft

(Roller, shaft, snap ring, collar, roll pin)

X07-51750 Lower Intermed. Roller, Soft

X07-0422 Oscillator Roller, Hard

Miscellaneous

XSA-1129 Water Pan Assy.

(w/ pan bolts)

X99-28 Water Pan Hose

XSA-9905 Water Bottle (w/cap)

X99-61 Wash Up Bottle

X88-81 Installation Manual


T-51@ANDSWING-AWAY@AREREGISTEREDTRADEMARKSOFTOWNSENDINDUSTRIES.

PRINTERS PARTS 800-543-1117 201-935-9595 fax 800-392-4072 201-935-5333 www.ppsnj.com

Adjustments

a. Metering to Pan

b. Form to Plate



Roller Description

P = Pan, Soft
M = Metering, Hard
UI = Upper Intermediate

LI = Lower Intermediate
O = Oscillator, Hard

F = Form, Soft

4/23/00