

# HEIDELBERG GTO 46 ALTRA

## Frequently Used Part Numbers

### Rollers

X07-0131	Form Roller, Soft
X07-0316	Pan Roller, Hard
X07-0427	Oscillator Roller, Hard
XSA-070217OSC	Metering Roller Assy., Soft (Roller, shaft, bearings, snap rings)
XSA-070511OSC	Intermediate Assy., Soft (Roller, shaft, bearings, collars, roll pin)
X07-0440	Aux. Rider
XSA-070440	Aux. Rider Kit (Includes bracket & spring assembly)

### SPECIAL NOTATION!!

These part numbers apply to all models with serial number 9302-09604 and higher except as follows:

9303-09553  
 9303-09642 to 9303-09645  
 9303-09804 to 9303-09807  
 9306-10605  
 9306-10606  
 9307-10864

### Upgrades

XSA-HEHANGALTRA  
 Adjustable Metering/Intermediate  
 Pressure (Does single unit)  
 Needed on Serial #9409-... & lower

### Side Frame Assemblies


XSA-010135	OPS Side Frame w/ bearing
XSA-010136	NOPS Side Frame w/ bearing

### Miscellaneous

X09-0101	Compression Springs (2 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)
XSA-1122	Water Pan Assy. (w/ pan bolts)
X99-29	Water Pan Hose
XSA-9905	Water Bottle (w/cap)
X99-61	Wash Up Bottle
X88-63	Installation Manual

### PRINTERS PARTS

800-543-1117 201-935-9595  
 fax 800-392-4072 201-935-5333  
 www.ppsnj.com



#### Adjustments

- a. Pan to Metering
- b. Metering to Intermediate
- c. Intermediate to Oscillator
- d. Oscillator to Form
- e. Form to Plate

#### Roller Description

P	=	Pan, Hard
M	=	Metering, Soft
I	=	Intermediate, Soft
O	=	Oscillator, Hard
F	=	Form, Soft
A	=	Aux. Rider