

TOKO 4750

Frequently Used Part Numbers

Rollers

X07-0129	Form Roller, Soft
X07-0331NS	Pan Roller, Soft
X07-0414A	Oscillator Roller, Hard
X07-0204NS	Metering Roller, Hard
XSA-070513	Intermed. Roller Assy., Soft (Roller, shaft, collars, roll pin) must specify for TK4750

Side Frame Assemblies

XSA-0108TKO	OPS Side Frame w/ Bearings
XSA-0108TKN	NOPS Side Frame w/ Bearings

Gears

XSA-03221538	Form Gear Assy. (w/ clutch bearing)
XSA-03221526	Pan Gear Assy. (w/ clutch bearing)
XSA-03221520	Upper Idler Gear Assy. (Gear, bushing, shoulder bolt)
XSA-03221526X	Lower Idler Gear Assy. (Gear, bushing, spool, washers, bolt)

Bearings

(After Serial number 9304-09982)	
X06-108	Sealed Ball Bearing, Side Frame (4 per dampener)
(Before Serial number 9304-09982)	
X06-346038	Thin Flanged Bushing, Side Frame (4 per dampener)
X06-324031	Flanged Bushing, Side Frame (2 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)


Miscellaneous

XSA-9903	Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
X09-0101	Compression Spring (2 per dampener)
X99-28	Water Pan Hose
XSA-9905	Water Bottle (w/ cap)
X99-61	Wash Up Bottle
X88-34	Installation Manual

PRINTERS PARTS
800-543-1117 201-935-9595
fax 800-392-4072 201-935-5333
www.ppsnj.com

Adjustments

- a. Metering to Pan
- b. Form to Plate



Roller Description

P	=	Pan, Soft
M	=	Metering, Hard
I	=	Intermediate, Soft
O	=	Oscillator, Hard
F	=	Form, Soft